

Switch2 system



Exit buttons

Robust metal exit button

Supplied with a choice of black or white bezels

3 sizes

Green LED

Complements PROXIMITY readers and keypads

About

Exit buttons may be used with Compact, Switch2 or Net2 systems. They are designed to match our range of PROXIMITY readers and keypads. The exit buttons are supplied with a choice of black or white fascias which can be fitted in the final stages of installation. The exit buttons are available in three sizes as shown in the illustration below.

Installation

The installation instructions show how the exit button is wired to Compact, Switch2 and Net2 systems. The E75 exit button fits on a standard UK recessed backbox.




The exit button with screw connectors is not pre-wired. It is supplied with rising clamp terminals at the rear.

Web links

http://paxton.info/28	Installation instructions
http://paxton.info/29	3D visual
http://paxton.info/104	Bezel colours
http://paxton.info/156	Scale drawing

Operation

The green LED is lit continuously. When the exit button is pressed, the green LED flashes to indicate that the door is unlocked (only when used with Switch2 and Net2).



Sales code	Description	Retail price
336-310	Exit button E38	£25.00
356-310	Exit button E50	£25.00
376-310	Exit button E75	£25.00
376-320	Exit button E75 with screw connector	£25.00