Premier Software & Peripherals







Upload/Download Software

Wintex Software

Texecom's user-friendly Windows[™] based software, designed for use with the Premier Series of control panels, provides complete upload/download and systems diagnostics for total control and flexibility.

Windows is a registered trademark of Microsoft Corporation

Monitoring Software

Montex Software

Software based alarm receiver interface for connecting with Premier ComIP alarm signalling equipment. Supports fast format, contact ID and SIA communication protocols. Manages received polling information for each monitored site.

Remote Maintenance Software

Maintex Software

Remote maintenance software compatible with Premier 48, 88 & 168 control panels. Automates remote maintenance procedure and provides database storage of maintenance information.

Wireless Diagnostics Software

Ricochet Monitor Software

Provides greater diagnostics and configuration control over wireless system setup than ever before. Delivers device status and attribute selection with real-time graphical representation of mesh-network wireless systems.

Alarm Management Software

Texbase Software

Texbase is an alarm management software package designed for use in conjunction with the Premier Com IP and Montex software, ideally suited to installers who wish to individually monitor their installed security systems for specific alarm signals. Texbase is event selectable, features include printable reports, detailed account history and alarm status emailing.




Software Peripherals



Key-Fob Programmer

The Key-fob Programmer allows configuration data to be copied from one control panel to another. This reduces programming time and simplifies set-up of multiple system installations.



Designed specifically for use with Wintex UDL software and a PC to allow trouble free uploading/downloading with Premier Series and Premier International Series control panels.



USB-Com

USB interface connector for connection between control panel and PC, enabling local upload/

Print-Com

Serial interface connector for connection between panel and serial type printers, enabling print-out of system events.

